

## AUDIO AND VISUAL SYSTEM


### PRECAUTION

#### 1. DISCONNECT AND RECONNECT CABLE OF NEGATIVE BATTERY TERMINAL

- (a) Before performing electronic work, disconnect the cable from the negative (-) battery terminal in order to prevent it from shorting and burning out.
- (b) Before disconnecting and reconnecting the battery cable, turn the ignition switch OFF and the headlight dimmer switch OFF. Then loosen the terminal nut completely. Do not damage the cable or terminal.
- (c) When the battery cable is disconnected, the clock and radio settings and stored DTCs are erased. Therefore, before disconnecting the battery cable, make a notes of them.


#### NOTICE:

**When the cable is disconnected from the negative (-) battery terminal, initialize the following system(s) after the cable is reconnected.**




System name	See procedure
METER / GAUGE SYSTEM	<a href="#">ME-10</a>

# PARTS LOCATION




\*: W/ WOOFER SPEAKER

AV



AV

# SYSTEM DIAGRAM



AV

## SYSTEM DESCRIPTION

### 1. CD PLAYER OUTLINE

- (a) A CD player uses a laser pickup to read digital signals recorded on CDs . By converting the digital signals to analog, music and other contents can be played.


**CAUTION:**

**Do not look directly at the laser pickup because the CD player uses an invisible laser beam. Be sure to operate the player only as instructed.**

**NOTICE:**

- **Do not disassemble any part of the CD player.**
- **Do not apply oil to the CD player.**
- **Do not insert anything but a CD into the CD player.**

- (b) Usable CDs



H

E119759

- (c) Precautions for use of discs

**NOTICE:**

- **Copy-protected CDs cannot be played.**
- **Dual discs cannot be played. Playing dual discs may cause malfunctions of the CD player.**
- **CD-Rs and CD-RWs may not be played depending on the recording conditions or characteristics of the discs, or due to damage, dirt, or deterioration caused by leaving the discs in the cabin for a long time.**
- **Unfinalized CD-Rs and CD-RWs cannot be played.**
- **PAL or SECAM color television standard discs cannot be played. (Only NTSC discs can be played.)**
- **Keep the discs away from dirt. Be careful not to damage the discs or leave your fingerprints on them.**
- **Hold discs by the outer edge and center hole with the label side up.**
- **Leaving the disc exposed halfway out of the slot for a long time after pressing the disc eject button may cause deformation of the disc, making the disc unusable.**

AV

- If discs have adhesive tape, stickers, CDR labels, or any traces of such labels attached, the discs may not be ejected or player malfunctions may result.
- Keep the discs away from direct sunlight. (Exposure to direct sunlight may cause deformation of the disc, making the disc unusable.)
- Do not use odd-shaped CDs because these may cause player malfunctions.
- Do not use discs whose recording portion is transparent or translucent because they may not be inserted, ejected, or played normally.

HINT:

- When it is cold or it is raining, if the windows mist up, mist and also dew may form in the player. In such a case, the CD may skip or the CD may stop in the middle of play. Ventilate or dehumidify the cabin for a while before using the player.
- The CD may skip if the player experiences strong vibrations when the vehicle is driven on rough road or similar uneven surface(s).

(d) Cleaning

**NOTICE:**

**Do not use a lens cleaner because it may cause a malfunction in the pickup portion of the player.**

- (1) If dirt is on the disc surface, wipe it clean with a soft dry cloth such as an eyeglass cleaner for plastic lenses from the center to the outside in a radial direction.

**NOTICE:**

- Pressing on the disc by hand or rubbing the disc with a hard cloth may scratch the disc surface.
- Use of solvent such as a record spray, antistatic agent, alcohol, benzine, and thinner, or a chemical cloth may cause damage to the disc, making the disc unusable.

**2. MP3/WMA OUTLINE**


(a) Playable MP3 file standards

Compatible standard	MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER 3)
Compatible sampling frequency	<ul style="list-style-type: none"> <li>• MPEG1 LAYER3: 32, 44.1, 48 (kHz)</li> <li>• MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)</li> </ul>
Compatible bit rate	<ul style="list-style-type: none"> <li>• MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps)</li> <li>• MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 160 (kbps)</li> <li>• Compatible with VBR</li> </ul>
Compatible channel mode	Stereo, joint stereo, dual channel, monaural

(b) Playable WMA file standards

Compatible standard	WMA Ver. 7, 8, and 9
Compatible sampling frequency	32, 44.1, 48 (kHz)

AV



Compatible bit rate	<ul style="list-style-type: none"> <li>• Ver. 7, 8: CBR48, 64, 80, 96, 128, 160, 192 (kbps)</li> <li>• Ver. 9: CBR48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)</li> <li>• Compatible with playback of channel 2 only</li> </ul>
---------------------	---

- (c) ID3 tags and WMA tags
  - (1) Additional textual information called ID3 tags can be input to MP3 files. Information such as song titles and artist names can be stored.  
 HINT:  
 This player is compatible with the ID3 tags of ID3 Ver. 1.0 and 1.1, and ID3 Ver. 2.2 and 2.3. (Number of characters complies with ID3 Ver. 1.0 and 1.1.)
  - (2) Additional textual information called WMA tags can be input to WMA files. Information such as song titles and artist names can be stored.
- (d) Usable media
  - (1) Only CD-ROMs, CD-Rs (CD-Recordable), and CD-RWs (CD-ReWritable) can be used to play MP3/WMA files.  
 NOTICE:
    - **CD-Rs and CD-RWs are more easily affected by a hot and humid environment than discs used for normal audio CDs. For this reason, some CD-Rs and CD-RWs may not be played.**
    - **If there are fingerprints or scratches on the disc, the disc may not be played or the CD may skip.**
    - **Some CD-Rs and CD-RWs deteriorate if they are left in the cabin for a long time.**
    - **Keep CD-Rs and CD-RWs in a storage case that is impenetrable to light.**
- (e) Usable media format
  - (1) Usable media format



Disc format	CD-ROM Mode 1, CD-ROM XA Mode 2 Form1
File format	ISO9660 Level 1 and Level 2 (Joliet and Romeo)

- HINT:
- As for MP3/WMA files written in any format other than those above, the contents of the files may not be played normally or the file names or folder names may not be displayed correctly.
  - This player is compatible with multi-session discs and can play CD-Rs and CD-RWs on which MP3/WMA files are added. However, only the first session can be played.
  - Discs whose first session includes both music data and MP3 or WMA format data cannot be played.

(2) Standard and restrictions

Maximum directory levels	8 levels
Maximum number of characters for a folder name/file name	32 characters

Maximum number of folders	192 (Including empty folders, route folders, and folders that do not contain MP3/WMA files)
Maximum number of files in a disc	255 (Including non-MP3/WMA files)

- (f) File names
- (1) Only files with an extension of ".mp3" or ".wma" can be recognized and played as MP3 or WMA files.
  - (2) Save MP3 or WMA files with an extension of ".mp3" or ".wma".
- NOTICE:**  
**If saving non-MP3 or non-WMA files with an extension of ".mp3" or ".wma", those files are wrongly recognized as MP3 or WMA files and played. A loud noise may occur and damage to the speakers may result.**

# HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

In accordance with the following procedures, troubleshoot the audio and visual system.

**1 VEHICLE BROUGHT TO WORKSHOP**

NEXT

**2 INSPECT BATTERY VOLTAGE**

**Standard Voltage:  
11 to 14 V**

If the voltage is below 11 V, recharge or replace the battery before proceeding.

NEXT

**3 BASIC INSPECTION**

- (a) Turn the ignition switch to ACC.
- (b) Check whether the display appears on the radio receiver.

Result	Proceed to
Display appears	A
Display does not appear	B

AV

**B** → **PROCEED TO PROBLEM SYMPTOMS TABLE**

A

**4 PROBLEM SYMPTOMS TABLE**

Result	Proceed to
Fault not listed in problem symptoms table	A
Fault listed in problem symptoms table	B

**B** → **Go to step 6**

A

**5 OVERALL ANALYSIS AND TROUBLESHOOTING**

- (a) Terminals of ECU (See page [AV-12](#))

NEXT

<b>6</b>	<b>ADJUST, REPAIR OR REPLACE</b>
----------	----------------------------------

**NEXT**

<b>7</b>	<b>CONFIRMATION TEST</b>
----------	--------------------------

**NEXT**

<b>END</b>
------------

# IDENTIFICATION OF NOISE SOURCE

## 1. Radio Description


(a) Radio frequency band

(1) Radio broadcasts use the radio frequency bands shown in the table below.

Frequency	30 kHz	300 kHz	30 MHz	30 MHz	300 MHz
Designation	LF	MF	HF	VHF	
Radio Wave		AM ↔		FM ↔	
Modulation	Amplitude modulation			Frequency modulation	

LF: Low Frequency      MF: Medium Frequency      HF: High Frequency      VHF: Very High Frequency

E108734E01




(b) Service area

(1) The service areas of AM and FM broadcasts are vastly different. Sometimes an AM broadcast can be received very clearly but an FM stereo cannot. FM stereo has the smallest service area, and is prone to pick up static and other types of interference such as noise.

(c) Radio reception problems


HINT:

In addition to static, other problems such as "phasing", "multipath", and "fade out" exist. These problems are not caused by electrical noise, but by the radio signal propagation method itself.




(1) Phasing

AM broadcasts are susceptible to electrical interference and another kind of interference called phasing. Occurring only at night, phasing is the interference created when a vehicle receives 2 radio wave signals from the same transmitter. One signal is reflected off the ionosphere and the other signal is received directly from the transmitter.



(2) Multipath  
 Multipath is a type of interference created when a vehicle receives 2 radio wave signals from the same transmitter. One signal is reflected off buildings or mountains and the other signal is received directly from the transmitter.



(3) Fade out  
 Fade out is caused by objects (buildings, mountains, and other such large obstacles) that deflect away part of a signal, resulting in a weaker signal when the object is between the transmitter and the vehicle. High frequency radio waves, such as FM broadcasts, are easily deflected by obstructions. Low frequency radio waves, such as AM broadcasts, are much more difficult to deflect.

(d) Noise problem  
 Technicians must have a clear understanding about each customer's noise complaint. Use the following table to diagnose noise problems.

Radio Frequency	Noise Occurrence Condition	Presumable Cause
AM	Noise occurs in a specified area	Foreign noise
AM	Noise occurs when listening to an intermittent broadcast	An identical program transmitted from multiple towers can cause noise where the signals overlap
AM	Noise occurs only at night	Music beat from a distant broadcast
FM	Noise occurs while driving in a specified area	Multipath or phasing noise resulting from a change in FM frequency

**HINT:**

If the noise does not match the examples above, refer to the descriptions about phasing and multipath.

## PROBLEM SYMPTOMS TABLE

### HINT:

Use the table below to determine the cause of the problem symptom. The potential causes of the symptom are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

### Audio Function


Symptom	Suspected area	See page
Noise occurs	1. Proceed to Noise Occurs	<a href="#">AV-14</a>
	2. Radio Receiver	-
Pressing power switch does not turn on system	1. Proceed to Pressing Power Switch does not Turn on System	<a href="#">AV-15</a>
	2. Proceed to Radio Receiver Power Source Circuit	<a href="#">AV-49</a>
	3. Radio Receiver	-
No sound can be heard from speakers (audio is mute)	1. Proceed to No Sound can be Heard from Speakers (Audio is Mute)	<a href="#">AV-16</a>
	2. Proceed to Speaker Circuit	<a href="#">AV-35</a>
	3. Proceed to Radio Receiver Power Source Circuit	<a href="#">AV-49</a>
	4. Proceed to Woofer Speaker Power Source Circuit (w/ woofer speaker)	<a href="#">AV-46</a>
	5. Radio Receiver	-
Sound quality is bad only when CD is played (volume is too low)	1. Proceed to Sound Quality is Bad Only when CD is played (Volume is too low)	<a href="#">AV-17</a>
	2. Proceed to Speaker Circuit	<a href="#">AV-35</a>
	3. Proceed to Woofer Speaker Power Source Circuit (w/ woofer speaker)	<a href="#">AV-51</a>
	4. Radio Receiver	-
CD cannot be ejected	1. Proceed to CD cannot be Ejected	<a href="#">AV-18</a>
	2. Proceed to Radio Receiver Power Source Circuit	<a href="#">AV-49</a>
	3. Radio Receiver	-
CD cannot be inserted / played or CD is ejected right after insertion	1. Proceed to CD cannot be Inserted / Played or CD is Ejected Right After Insertion	<a href="#">AV-19</a>
	2. Proceed to Radio Receiver Power Source Circuit	<a href="#">AV-49</a>
	3. Radio Receiver	-
CD sound skips	1. Proceed to CD Sound Skips	<a href="#">AV-21</a>
	2. Radio Receiver	-
Radio broadcast cannot be received (bad reception)	1. Proceed to Radio Broadcast cannot be Received (Bad Reception)	<a href="#">AV-23</a>
Poor sound quality in all modes (low volume)	1. Proceed to Poor Sound Quality in All Modes (Low Volume)	<a href="#">AV-25</a>
	2. Proceed to Speaker Circuit	<a href="#">AV-35</a>
	3. Radio Receiver	-
Radio receiver cannot be illuminated at night	1. Proceed to Illumination Circuit	<a href="#">AV-30</a>
	2. Radio Receiver	-
External device sound cannot be heard or sound quality is bad. (Stereo jack is used.)	1. Proceed to Sound Signal Circuit between Radio Receiver and Stereo Jack Adapter	<a href="#">AV-43</a>
	2. Stereo Jack Adapter	-
	3. Noise Filter	-
	4. Radio Receiver	-
Woofer system cannot be operated with woofer speaker switch (w/ woofer speaker)	1. Proceed to Woofer Speaker Switch Circuit	<a href="#">AV-46</a>
	2. Radio Receiver	-
	3. Proceed to Woofer Speaker Power Source Circuit	<a href="#">AV-51</a>

**Steering Pad Switch Function**

Symptom	Suspected area	See page
Audio system cannot be operated with steering pad switch	1. Proceed to Steering Pad Switch Circuit	<a href="#">AV-26</a>
	2. Radio Receiver	-
Steering pad switch cannot be illuminated at night	1. Proceed to Illumination Circuit	<a href="#">AV-30</a>
	2. Radio Receiver	-

# TERMINALS OF ECU

## 1. CHECK RADIO RECEIVER



- (a) Disconnect the E41 receiver connector.
- (b) Measure the resistance and voltage of the wire harness side connector.

### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (E41-7) - Body ground	BR - Body ground	Ground	Always	Below 1 Ω
B (E41-4) - GND (E41-7)	L-Y - BR	Battery	Always	11 to 14 V
ACC (E41-3) - GND (E41-7)	GR - BR	ACC power supply	Ignition switch OFF	Below 1 V
			Ignition switch ACC	11 to 14 V

### HINT:

If the results are not as specified, there may be a malfunction in the wire harness.

- (c) Reconnect the E41 receiver connector.
- (d) Measure the voltage of the connector.

### Standard voltage:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specification
ILL+ (E41-10) - GND (E41-7)	G - BR	Illumination signal	Light control switch OFF	Below 1 V
			Light control switch TAIL	11 to 14 V
ILL- (E42-5) - GND (E41-7)	BR-W - BR	Illumination signal	Light control switch OFF	Below 1 V
			Light control switch TAIL	11 to 14 V
FR+ (E41-1) - GND (E41-7)	LG - BR	Sound signal (Front right)	Audio system is playing	A waveform synchronized with sound is output
FR- (E41-5) - GND (E41-7)	L - BR	Sound signal (Front right)	Audio system is playing	A waveform synchronized with sound is output
FL+ (E41-2) - GND (E41-7)	P - BR	Sound signal (Front left)	Audio system is playing	A waveform synchronized with sound is output
FL- (E41-6) - GND (E41-7)	V - BR	Sound signal (Front left)	Audio system is playing	A waveform synchronized with sound is output
RR+ (E42-1) - GND (E41-7)	R - BR	Sound signal (Rear right)	Audio system is playing	A waveform synchronized with sound is output
RR- (E42-3) - GND (E41-7)	W - BR	Sound signal (Rear right)	Audio system is playing	A waveform synchronized with sound is output
RL+ (E42-2) - GND (E41-7)	B - BR	Sound signal (Rear left)	Audio system is playing	A waveform synchronized with sound is output
RL- (E42-6) - GND (E41-7)	Y - BR	Sound signal (Rear left)	Audio system is playing	A waveform synchronized with sound is output
AMP (E41-9) - GND (E41-7)*1	P-L - BR	Woofer speaker signal	Woofer speaker switch OFF	Below 1 V
			Woofer speaker switch ON	11 to 14 V

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specification
SWG (E43-6) - GND (E41-7)	W-R - BR	Steering pad switch ground	Always	Below 1 V
SW1 (E43-7) - GND (E41-7)	V-W - BR	Steering pad switch signal	Steering pad switch not operated	4 V or more
			SEEK+ switch pushed	Approximately 0.5 V
			SEEK- switch pushed	Approximately 0.9 V
			VOL+ switch pushed	Approximately 2.0 V
			VOL- switch pushed	Approximately 3.4 V
SW2 (E43-8) - GND (E41-7)	Y-B - BR	Steering pad switch signal	Steering pad switch not operated	4 V or more
			MODE switch pushed	Approximately 0.5 V
			ON HOOK switch pushed	Approximately 0.9 V
			OFF HOOK switch pushed	Approximately 2.0 V
			VOICE switch pushed	Approximately 3.4 V
ARI (E43-15) - GND (E41-7)	P - BR	Sound signal (Right)	External device is playing (When stereo jack adapter is used)	A waveform synchronized with sound is output
ASGN (E43-16) - GND (E41-7)	(Shielded) - BR	Ground (Shielded)	Always	Below 1 V
ALI (E43-17) - GND (E41-7)	L - BR	Sound signal (Left)	External device is playing (When stereo jack adapter is used)	A waveform synchronized with sound is output
AUXI (E43-19) - GND (E41-7)	P-G - BR	External device connection detection signal	External device is connected	Below 1 V

\*1: w/ Woofer Speaker

HINT:

If the results are not as specified, there may be a malfunction in the wire harness.

**Noise Occurs****INSPECTION PROCEDURE****1 CHECK SPEAKER INSTALLATION**

(a) Check that each speaker is securely installed.

**OK:**

**Speakers are installed securely.**

**HINT:**

The radio has a noise prevention function to reduce noise when listening to the radio. If severe noise occurs, check whether the ground at the antenna mounting base and the noise prevention unit are installed and wired correctly.

Condition in Which Noise Occurs	Noise Type
Increases when accelerator pedal is depressed, and stops immediately when engine is stopped	Generator noise
When A/C or heater is operating	Blower motor noise
<ul style="list-style-type: none"> <li>When vehicle is rapidly accelerated on unpaved road</li> <li>When ignition switch is ON</li> </ul>	Fuel pump noise
<ul style="list-style-type: none"> <li>When horn switch is pressed and released</li> <li>When horn switch is pressed and held down</li> </ul>	Horn noise
Occurs faintly when engine is running, and stops immediately when engine is stopped	Ignition noise
When turn signal is operating	Flasher noise
When window washer is operating	Washer noise
When engine is running, and continues even when engine is stopped	Engine coolant temperature noise
When wipers are operating	Wiper noise
When brake pedal is depressed	Stop light switch noise
Other than above	Static electricity on vehicle

**HINT:**

- Use the table above to identify the part that is causing the noise. Check the noise filter on the part.
- To save time and avoid a misdiagnosis, first make sure that the noise is not originating from outside the vehicle.
- Troubleshoot noise problems in order of loudness, starting with the loudest noise.
- Setting the radio to a frequency that receives no signal may make recognition of the noise problem easier.

**NG**

**INSTALL SPEAKER PROPERLY**

**OK**

**IDENTIFY NOISE SOURCE**

**Pressing Power Switch does not Turn on System****INSPECTION PROCEDURE****1 CHECK WHETHER RAPID TEMPERATURE CHANGE OCCURRED IN CABIN**

- (a) Check whether or not a rapid temperature change occurred in the cabin.

**OK:**

**Rapid temperature change occurred.**

**HINT:**

Rapid temperature changes create condensation inside the radio receiver, which may cause a short circuit.

**NG**

**REPLACE RADIO RECEIVER**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**No Sound can be Heard from Speakers****INSPECTION PROCEDURE****1 CHECK RADIO RECEIVER (VOLUME AND MUTE SWITCH)**

- (a) Check the radio receiver setting.
- (1) Check that the volume is not set to minimum.
  - (2) Check that MUTE is OFF.

**OK:****Malfunction disappears.****NG****PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN IN PROBLEM SYMPTOMS TABLE****OK****END**

**Sound Quality is Bad Only when CD is Played (Volume is Too Low)****INSPECTION PROCEDURE****1 OPERATION USING ANOTHER CD**

- (a) Replace the CD with a normal one and check if the same problem occurs again.

**OK:**

**Malfunction disappears.**

**NG**

**PROCEED TO NEXT CIRCUIT INSPECTION  
SHOWN IN PROBLEM SYMPTOMS TABLE**

**OK**

**CD IS FAULTY**

**CD cannot be Ejected****INSPECTION PROCEDURE****1 CHECK OPERATION**

- (a) Press the CD EJECT switch of the radio receiver for 2 seconds or more to check whether the CD can be ejected.

**OK:**

**CD is ejected.**

**NG** 

**REPLACE RADIO RECEIVER**

**OK** 

**2 OPERATION USING ANOTHER CD**

- (a) Replace the CD with a normal one and check that the CD can be ejected.

**OK:**

**CD is ejected.**

**NG** 

**REPLACE RADIO RECEIVER**

**OK** 

**CD IS FAULTY**

**AV**

## CD cannot be Inserted or is Ejected Right After Insertion

### INSPECTION PROCEDURE

#### 1 CHECK CD

- (a) Make sure that the CD is a normal audio CD, and that it is not deformed, flawed, stained, burred or otherwise defective.

**OK:**

**Normal audio CD.**

**HINT:**

Translucent or uniquely-shaped CDs cannot be played.

**NG**

**CD IS FAULTY**

**OK**

#### 2 CHECK THAT CD HAS BEEN INSERTED PROPERLY

- (a) Check whether or not the CD was inserted upside down.

**OK:**


**CD was properly inserted.**

**NG**

**INSERT CD PROPERLY**

**OK**

#### 3 CLEAN CD



- (a) Clean the disc by wiping the CD's dataside radially with a soft cloth.

**OK:**

**Malfunction disappears.**

**NOTICE:**

**Do not use a conventional record cleaner or anti-static preservative.**

**OK**

**CD WAS DIRTY**

**NG**

#### 4 REPLACE CD

- (a) Replace the CD with a normal one and check if the same problem occurs again.

**OK:**

**Malfunction disappears.**

**NG**

**REPLACE RADIO RECEIVER**

OK

CD IS FAULTY


## CD Sound Skips

### INSPECTION PROCEDURE

HINT:

The sound may skip when driving on an unpaved road.

#### 1 CLEAN CD



- (a) If the disc is dirty, clean the disc by wiping the CD's dataside radially with a soft cloth.

**OK:**

**Malfunction disappears.**

**NOTICE:**

**Do not use a conventional record cleaner or anti-static preservative.**

OK

CD WAS DIRTY

NG

#### 2 OPERATION USING ANOTHER CD

- (a) Replace the CD with a normal one and check if the same problem occurs again.

**OK:**

**Malfunction disappears.**

OK

CD IS FAULTY

NG

#### 3 CHECK RADIO RECEIVER INSTALLATION

- (a) Check the installation condition of the radio receiver.

**OK:**

**Installed properly.**

NG

INSTALL RADIO RECEIVER PROPERLY

OK

#### 4 CHECK WHETHER RAPID TEMPERATURE CHANGE OCCURRED IN CABIN

- (a) Check whether or not a rapid temperature change occurred in the cabin.

**OK:**

**Rapid temperature change occurred.**

HINT:

Rapid temperature changes create condensation inside the CD player, which may prevent CDs from being played.

NG

REPLACE RADIO RECEIVER

OK

CONDENSATION DUE TO TEMPERATURE CHANGE (LET IT SIT FOR A WHILE BEFORE USING)

## Radio Broadcast cannot be Received (Bad Reception)

### INSPECTION PROCEDURE

#### 1 CHECK WHETHER RAPID TEMPERATURE CHANGE OCCURRED IN CABIN

- (a) Check whether the radio auto-search functions properly.  
 (1) Tune the radio using the auto-search function and check that it operates normally.

**OK:**

The radio auto-search functions properly.

OK

END

NG

#### 2 CHECK OPTIONAL COMPONENTS

- (a) Check whether any optional components, such as telephone antenna, are installed.

**OK:**

Optional component(s) installed.

OK

EFFECT FROM OPTIONAL COMPONENTS

NG

AV

#### 3 CHECK ANTENNA FOR NOISE PRODUCTION

- (a) With the ignition switch ON, turn on the radio and select the AM mode.  
 (b) Place the tip of a screwdriver on the antenna and check that noise is heard from the speakers.

**OK:**


Noise occurs.

OK

REPLACE RADIO RECEIVER

NG

#### 4 INSPECT RADIO RECEIVER (ANTENNA)



- (a) Remove the antenna plug of the radio receiver.  
 (b) With the radio receiver connector connected, turn the ignition switch on (ACC).  
 (c) Turn on the radio and select the AM mode.  
 (d) Place a flat-head screwdriver or piece of metal, such as a thin wire, on the antenna jack of the radio receiver. Check that noise is heard from the speakers.

**OK:**

Noise occurs.

NG

REPLACE ROOF ANTENNA POLE SUB-  
ASSEMBLY

OK

REPLACE RADIO RECEIVER

**Poor Sound Quality in All Modes (Low Volume)****INSPECTION PROCEDURE****1 ADJUST SOUND QUALITY**

- (a) Operate the radio receiver to adjust the sound quality.

**OK:**

**Sound quality returns to normal.**

**OK** →

**SYSTEM IS OK (POOR SOUND QUALITY)**

**NG**

**2 COMPARE WITH ANOTHER VEHICLE OF SAME MODEL**

- (a) Compare the vehicle with another vehicle that has a normally functioning audio system. Check if there is any difference in the sound quality.

**OK:**

**No difference is found.**

**OK** →

**SYSTEM IS OK (POOR SOUND QUALITY)**

**NG**


**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

## Steering Pad Switch Circuit

### DESCRIPTION

This circuit sends an operation signal from the steering pad switch to the radio receiver. If there is an open in the circuit, the audio system cannot be operated using the steering pad switch. If there is a short in the circuit, the same condition as that when the switch is continuously depressed occurs. Therefore, the radio receiver cannot be operated using the steering pad switch, and also the radio receiver itself cannot function.

### WIRING DIAGRAM




**INSPECTION PROCEDURE**

**NOTICE:**

The vehicle is equipped with an SRS (Supplemental Restraint System) which includes components such as airbags. Before servicing (including removal or installation of parts), be sure to read the precautionary notice for the Supplemental Restraint System (See page RS-1).

**1 INSPECT RADIO RECEIVER**



- (a) Disconnect the E43 radio receiver connector.
- (b) Measure the resistance.

**Standard resistance**

Tester connection	Condition	Specified condition
E43-7 (SW1) - E43-6 (SWG)	No switches pushed	Approximately 100 kΩ
E43-7 (SW1) - E43-6 (SWG)	SEEK+ switch pushed	Approximately 0 Ω
E43-7 (SW1) - E43-6 (SWG)	SEEK- switch pushed	Approximately 0.3 kΩ
E43-7 (SW1) - E43-6 (SWG)	VOL+ switch pushed	Approximately 1 kΩ
E43-7 (SW1) - E43-6 (SWG)	VOL- switch pushed	Approximately 3.2 kΩ
E43-8 (SW2) - E43-6 (SWG)	No switches pushed	Approximately 100 kΩ
E43-8 (SW2) - E43-6 (SWG)	MODE switch pushed	Approximately 0 Ω

- (c) Reconnect the radio receiver connector.

**AV**

**NG** → **Go to step 2**


**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**2 INSPECT STEERING PAD SWITCH ASSEMBLY**

- (a) Disconnect the E17 steering pad switch assembly connector.

Wire Harness Side:



E130787E01

(b) Measure the resistance.

**Standard resistance**

Tester connection	Condition	Specified condition
E17-12 (AU1) - E17-10 (EAU)	No switches pushed	Approximately 100 kΩ
E17-12 (AU1) - E17-10 (EAU)	SEEK+ switch pushed	Approximately 0 Ω
E17-12 (AU1) - E17-10 (EAU)	SEEK- switch pushed	Approximately 0.3 kΩ
E17-12 (AU1) - E17-10 (EAU)	VOL+ switch pushed	Approximately 1 kΩ
E17-12 (AU1) - E17-10 (EAU)	VOL- switch pushed	Approximately 3.2 kΩ
E17-11 (AU2) - E17-10 (EAU)	No switches pushed	Approximately 100 kΩ
E17-11 (AU2) - E17-10 (EAU)	MODE switch pushed	Approximately 0 Ω


(c) Reconnect the steering pad switch assembly connector.

<b>NG</b>	<b>REPLACE STEERING PAD SWITCH ASSEMBLY</b>
-----------	---

**AV**

OK

**3 INSPECT SPIRAL CABLE**



- (a) Disconnect the E17 steering pad switch assembly and spiral cable connectors.
- (b) Measure the resistance.  
**Standard resistance**

Tester connection	Specified condition
Terminal 10 (EAU) main switch side - EAU (E17-10)	Below 1 Ω
Terminal 12 (AU1) main switch side - AU1 (E17-12)	Below 1 Ω
Terminal 11 (AU2) main switch side - AU2 (E17-11)	Below 1 Ω

**NOTICE:**

The spiral cable is an important part of the SRS airbag system. Incorrect removal or installation of the spiral cable may prevent the airbag from deploying. Be sure to read the page shown in the brackets.

**HINT:**

- Removal (See page [RS-357](#))
- Installation (See page [RS-358](#))

- (c) Reconnect the steering pad switch assembly connector.
- (d) Reconnect the spiral cable connector.

**NG** → **REPLACE SPIRAL CABLE**

**AV** OK


**REPAIR OR REPLACE HARNESS OR CONNECTOR (SPIRAL CABLE - RADIO RECEIVER)**

## Illumination Circuit

### DESCRIPTION

Power is supplied to the radio receiver and steering pad switch assembly illumination when the light control switch is in the TAIL or HEAD position.

### WIRING DIAGRAM



E130782E01

### INSPECTION PROCEDURE

#### NOTICE:

The vehicle is equipped with an SRS (Supplemental Restraint System) which includes components such as airbags. Before servicing (including removal or installation of parts), be sure to read the precautionary notice for the supplemental restraint system (See page [RS-1](#)).

**1 CHECK ILLUMINATION**

- (a) Check if the illumination for the radio receiver, steering pad switch, or others (back sonar switch, hazard switch, etc.) comes on when the light control switch is turned to the HEAD or TAIL position.

**Result**

Result	Proceed to
Illumination comes on for all components except steering pad switch.	A
Illumination comes on for all components except radio receiver.	B
No illumination comes on (radio receiver, back sonar switch, hazard switch, etc.).	C

**B** → **GO TO LIGHTING SYSTEM**


**C** → **Go to step 6**

**A**

**2 INSPECT STEERING PAD SWITCH ASSEMBLY**

- (a) Disconnect the steering pad switch assembly connector.
- (b) Connect the positive (+) lead to terminal ILL+ and the negative (-) lead to terminal EAU of the steering pad switch assembly connector.

**AV**



- (c) Check if the illumination for the steering pad switch assembly comes on.


**OK:**

**Illumination for the steering pad switch assembly comes on.**

**NG** → **REPLACE STEERING PAD SWITCH ASSEMBLY**

OK

**3 INSPECT SPIRAL CABLE**



- (a) Disconnect the E17 steering pad switch assembly and spiral cable connectors.
- (b) Measure the resistance.

**Standard resistance**

Tester connection	Specified condition
Terminal 10 (EAU) main switch side - EAU (E17-10)	Below 1 Ω
Terminal 1 (ILL+) main switch side - ILL+ (E17-1)	Below 1 Ω

**NOTICE:**

The spiral cable is an important part of the SRS airbag system. Incorrect removal or installation of the spiral cable may prevent the airbag from deploying. Be sure to read the page shown in the brackets.

**HINT:**


- Removal (See page RS-357)
- Installation (See page RS-358)

- (c) Reconnect the steering pad switch assembly connector.
- (d) Reconnect the spiral cable connector.

**NG** REPLACE SPIRAL CABLE

OK

**4 CHECK HARNESS AND CONNECTOR (BATTERY - SPIRAL CABLE)**



- (a) Disconnect the E17 spiral cable connector.
- (b) Measure the voltage.

**Standard voltage**


Tester connection	Condition	Specified condition
E17-1 (ILL+) - Body ground	Light control SW TAIL or HEAD	11 to 14 V

- (c) Reconnect the spiral cable connector.

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

**5 CHECK HARNESS AND CONNECTOR (SPIRAL CABLE - RADIO RECEIVER)**



- (a) Disconnect the E43 receiver connector.
- (b) Disconnect the E17 spiral cable connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E43-6 (SWG) - E17-10 (SWG)	Below 1 Ω
E43-6 (SWG) or E17-10 (SWG) - Body ground	10 kΩ or higher


- (d) Reconnect the receiver connector.
- (e) Reconnect the spiral cable connector.

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**AV REPLACE RADIO RECEIVER**

**6 CHECK HARNESS AND CONNECTOR (BATTERY - RADIO RECEIVER)**



- (a) Disconnect the E41 receiver connector.
- (b) Measure the voltage.

**Standard voltage**

Tester connection	Condition	Specified condition
E41-10 (ILL+) - Body ground	Light control SW TAIL or HEAD	11 to 14 V

- (c) Reconnect the receiver connector.


**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**7 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - LIGHT CONTROL RHEOSTAT)**


**Wire Harness Side:**

Radio Receiver Connector



Front View

Light Control Rheostat Connector



Front View

E130786E01

- (a) Disconnect the E42 receiver connector.
- (b) Disconnect the E4 light control rheostat connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E42-6 (ILL-) - E4-3 (-)	Below 1 $\Omega$
E42-6 (ILL-) or E4-3 (-) - Body ground	10 k $\Omega$ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the light control rheostat connector.

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**


**RADIO RECEIVER**


# Speaker Circuit

## DESCRIPTION

Sound signals that have been amplified by the stereo component amplifier are sent to the speakers from the radio receiver through this circuit. If there is a short in this circuit, the sound cannot be heard from the speakers even though there is no malfunction in the speakers.

## WIRING DIAGRAM





AV

### INSPECTION PROCEDURE

<b>1</b>	<b>CHECK SPEAKER</b>
----------	----------------------

(a) Check whether sound is emitted from each speaker.

**Result**

Result	Proceed to
Front No. 1 speakers have problems	A
Front No. 2 speakers have problems	B
Rear speakers have problems	C
Woofer speaker has problems (w/ woofer speaker)	D
Roof speakers have problems	E

- B** → Go to step 4
- C** → Go to step 6
- D** → Go to step 8
- E** → Go to step 10

**A**

**2 INSPECT FRONT NO. 1 SPEAKERS**

- (a) Check the left and right front No. 1 speakers (See page AV-58).

**OK:**

Front No. 1 speakers are normal.

**NG** → REPLACE FRONT NO. 1 SPEAKER

**OK**

**3 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - FRONT NO. 1 SPEAKER)**

- (a) Disconnect the E41 receiver connector.  
 (b) Disconnect the G4 and H4 front No. 1 speaker connectors.  
 (c) Measure the resistance.


**Standard resistance**

Tester Connection	Specified Condition
E41-2 (FL+) - H4-1	Below 1 Ω
E41-6 (FL-) - H4-2	Below 1 Ω
E41-2 (FL+) or H4-1 - Body ground	10 kΩ or higher
E41-6 (FL-) or H4-2 - Body ground	10 kΩ or higher
E41-1 (FR+) - G4-1	Below 1 Ω
E41-5 (FR-) - G4-2	Below 1 Ω
E41-1 (FR+) or G4-1 - Body ground	10 kΩ or higher
E41-5 (FR-) or G4-2 - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.  
 (e) Reconnect the front No. 1 speaker connectors.

**NG** → REPAIR OR REPLACE HARNESS OR CONNECTOR

**AV**



**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**4 INSPECT FRONT NO. 2 SPEAKERS**

- (a) Check the left and right front No. 2 speakers (See page [AV-61](#)).


**OK:**

Front No. 2 speakers are normal.

**NG** → **REPLACE FRONT NO. 2 SPEAKER**

**OK**

**5 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - FRONT NO. 2 SPEAKER)**



- (a) Disconnect the E41 receiver connector.
- (b) Disconnect the F3 and F4 front No. 2 speaker connectors.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E41-2 (FL+) - F4-4	Below 1 Ω
E41-6 (FL-) - F4-3	Below 1 Ω
E41-2 (FL+) or F4-4 - Body ground	10 kΩ or higher
E41-6 (FL-) or F4-3 - Body ground	10 kΩ or higher
E41-1 (FR+) - F3-4	Below 1 Ω
E41-5 (FR-) - F3-3	Below 1 Ω
E41-1 (FR+) or F3-4 - Body ground	10 kΩ or higher
E41-5 (FR-) or F3-3 - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the front No. 2 speaker connectors.

**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**6 INSPECT REAR SPEAKERS**

- (a) Check the left and right rear speakers (See page [AV-69](#)).


**OK:**

Rear speakers are normal.

**NG** → **REPLACE REAR SPEAKER**

**OK**

**7 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - REAR SPEAKER)**



- (a) Disconnect the E42 receiver connector.
- (b) Disconnect the L9 and L18 rear speaker connectors.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E42-2 (RL+) - L9-1	Below 1 Ω
E42-6 (RL-) - L9-2	Below 1 Ω
E42-2 (RL+) or L9-1 - Body ground	10 kΩ or higher
E42-6 (RL-) or L9-2 - Body ground	10 kΩ or higher
E42-1 (RR+) - L18-1	Below 1 Ω
E42-3 (RR-) - L18-2	Below 1 Ω
E42-1 (RR+) or L18-1 - Body ground	10 kΩ or higher
E42-3 (RR-) or L18-2 - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the rear speaker connectors.

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**AV** **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**8 INSPECT WOOFER SPEAKER**

- (a) Check the woofer speaker.


**OK:**

**Woofer speaker is normal.**

**NG** **REPLACE WOOFER SPEAKER**

**OK**

**9 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - WOOFER SPEAKER)**



- (a) Disconnect the E42 receiver connector.
- (b) Disconnect the K4 woofer speaker connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E42-2 (RL+) - K4-2 (L+)	Below 1 Ω
E42-6 (RL-) - K4-6 (L-)	Below 1 Ω
E42-2 (RL+) or K4-2 (L+) - Body ground	10 kΩ or higher
E42-6 (RL-) or K4-6 (L-) - Body ground	10 kΩ or higher
E42-1 (RR+) - K4-1 (R+)	Below 1 Ω
E42-3 (RR-) - K4-5 (R-)	Below 1 Ω
E42-1 (RR+) or K4-1 (R+) - Body ground	10 kΩ or higher
E42-3 (RR-) or K4-5 (R-) - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the woofer speaker connector.

**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

**AV**


**10 INSPECT ROOF SPEAKERS**

- (a) Check the left and right roof speakers (See page AV-82).
- OK:**  
Roof speakers are normal.

**NG** **REPLACE ROOF SPEAKER**

**OK**

**11 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - CONDENSER)**



- (a) Disconnect the E42 receiver connector.
- (b) Disconnect the E27 condenser connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E42-2 (RL+) - E27-2 (LI+)	Below 1 Ω
E42-6 (RL-) - E27-1 (LI-)	Below 1 Ω
E42-2 (RL+) or E27-2 (LI+) - Body ground	10 kΩ or higher
E42-6 (RL-) or E27-1 (LI-) - Body ground	10 kΩ or higher
E42-1 (RR+) - E27-4 (RI+)	Below 1 Ω
E42-3 (RR-) - E27-3 (RI-)	Below 1 Ω
E42-1 (RR+) or E27-4 (RI+) - Body ground	10 kΩ or higher
E42-3 (RR-) or E27-3 (RI-) - Body ground	10 kΩ or higher


- (d) Reconnect the receiver connector.
- (e) Reconnect the condenser connector.

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

**OK**

**AV**

**12 CHECK HARNESS AND CONNECTOR (CONDENSER - ROOF SPEAKER)**



- (a) Disconnect the E42 receiver connector.
- (b) Disconnect the E27 condenser connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E27-2 (LO+) - R4-1	Below 1 Ω
E27-5 (LO-) - R4-2	Below 1 Ω
E27-2 (LO+) or R4-1 - Body ground	10 kΩ or higher
E27-5 (LO-) or R4-2 - Body ground	10 kΩ or higher
E27-8 (RO+) - R5-1	Below 1 Ω
E27-7 (RO-) - R5-2	Below 1 Ω
E27-8 (RO+) or R5-1 - Body ground	10 kΩ or higher
E27-7 (RO-) or R5-2 - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the condenser connector.

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

**13** REPLACE CONDENSER

- (a) Temporarily replace the condenser with a new or normally functioning one.
- (b) Check that the sound is normal.

**OK:**

**Sound is normal.**

NG

END

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**


## Sound Signal Circuit between Radio Receiver and Stereo Jack Adapter

### DESCRIPTION

The stereo jack adapter sends an external device sound signal to the radio receiver through this circuit. The sound signal that has been sent is amplified by the stereo component amplifier, and then is sent to the speakers.

If there is an open or short in the circuit, sound cannot be heard from the speakers even if there is no malfunction in the stereo component amplifier, radio receiver, or speakers.


### WIRING DIAGRAM



AV

**INSPECTION PROCEDURE**

**1 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - NOISE FILTER)**



(a) Disconnect the E71 noise filter and E43 radio receiver connectors.

(b) Measure the resistance.

**Standard resistance**

Tester connection	Specified condition
E71-5 (AUXO) - E43-19 (AUXI)	Below 1 Ω
E71-8 (ALO) - E43-17 (ALI)	Below 1 Ω
E71-7 (ARO) - E43-15 (ARI)	Below 1 Ω
E71-6 (ASGO) - E43-16 (ASGN)	Below 1 Ω
E71-5 (AUXO) or E43-19 (AUXI) - Body ground	10 kΩ or higher
E71-8 (ALO) or E43-17 (ALI) - Body ground	10 kΩ or higher
E71-7 (ARO) or E43-15 (ARI) - Body ground	10 kΩ or higher
E71-6 (ASGO) or E43-16 (ASGN) - Body ground	10 kΩ or higher

(c) Reconnect the noise filter connector.

(d) Reconnect the radio receiver connector.


**MG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

**AV**

**2 CHECK HARNESS AND CONNECTOR (NOISE FILTER - STEREO JACK ADAPTER)**



(a) Disconnect the E26 stereo jack adapter and E71 noise filter connectors.

(b) Measure the resistance.

**Standard resistance**

Tester connection	Specified condition
E26-1 (ALO) - E71-1 (ALI)	Below 1 Ω
E26-2 (ARO) - E71-2 (ARI)	Below 1 Ω
E26-3 (ASGN) - E71-3 (ASG1)	Below 1 Ω
E26-1 (ALO) or E71-1 (ALI) - Body ground	10 kΩ or higher
E26-2 (ARO) or E71-2 (ARI) - Body ground	10 kΩ or higher
E26-3 (ASGN) or E71-3 (ASG1) - Body ground	10 kΩ or higher

(c) Reconnect the stereo jack adapter connector.

(d) Reconnect the noise filter connector.

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE


## Woofer Speaker Switch Circuit

### DESCRIPTION

This is the circuit between the radio receiver and the woofer speaker. When the woofer speaker switch is turned ON and OFF, the woofer speaker is activated and deactivated through control of the signals between the receiver and the woofer speaker.

If there is an open or short in the circuit, sound cannot be heard from the woofer speaker even if there is no malfunction in the radio receiver or woofer speaker.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

**AV**

#### 1 INSPECT WOOFER SPEAKER SWITCH

- (a) Check the woofer speaker switch (See page [AV-127](#)).

**OK:**

Woofer speaker switch is normal.

**NG**


**REPLACE WOOFER SPEAKER SWITCH**

**OK**


**2 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - WOOFER SPEAKER SWITCH)**

**Wire Harness Side:**

Woofers Speaker Switch Connector



Radio Receiver Connector



E130775E01

- (a) Disconnect the E41 receiver connector.
- (b) Disconnect the E5 woofer speaker switch connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E41-9 (AMP) - E5-3	Below 1 Ω
E41-9 (AMP) or E5-3 - Body ground	10 kΩ or higher

- (d) Reconnect the receiver connector.
- (e) Reconnect the woofer speaker switch connector.


**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

**OK**


**3 CHECK HARNESS AND CONNECTOR (WOOFER SPEAKER - WOOFER SPEAKER SWITCH)**

**Wire Harness Side:**

Woofers Speaker Switch Connector



Woofers Speaker Connector



E130776E01

- (a) Disconnect the K4 woofer speaker connector.
- (b) Disconnect the E5 woofer speaker switch connector.
- (c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
K4-9 (AMP+) - E5-4	Below 1 Ω
K4-9 (AMP+) or E5-4 - Body ground	10 kΩ or higher

- (d) Reconnect the woofer speaker connector.
- (e) Reconnect the woofer speaker switch connector.

**NG** REPAIR OR REPLACE HARNESS OR CONNECTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

## Radio Receiver Power Source Circuit

### DESCRIPTION

This circuit provides power to the radio receiver.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

#### 1 INSPECT FUSE (ACC, AM1, RADIO NO. 1)

- (a) Remove the ACC fuse from the main body ECU.
- (b) Remove the AM1 fuse and RADIO NO. 1 fuse from the engine room R/B.

(c) Measure the resistance of the fuses.

**Standard resistance:**


**Below 1 Ω**

(d) Reinstall the fuses.

**NG** → **REPLACE FUSE**

**OK**

**2 CHECK HARNESS AND CONNECTOR (RADIO RECEIVER - BATTERY AND BODY GROUND)**



(a) Disconnect the E41 receiver connector.

(b) Measure the voltage.

**Standard voltage**

Tester Connection	Condition	Specified Condition
E41-4 (B) - Body ground	Always	11 to 14 V
E41-3 (ACC) - Body ground	Ignition switch ACC	11 to 14 V

(c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
E41-7 (GND) - Body ground	Below 1 Ω

(d) Reconnect the receiver connector.

**NG** → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**


**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

## Woofer Speaker Power Source Circuit

### DESCRIPTION

This circuit provides power to the woofer speaker.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

#### 1 INSPECT FUSE (ACC, AM1, RADIO NO. 2)

- (a) Remove the ACC fuse from the main body ECU.
- (b) Remove the AM1 fuse and RADIO NO. 2 fuse from the engine room R/B.

(c) Measure the resistance of the fuses.

**Standard resistance:**


**Below 1 Ω**

(d) Reinstall the fuses.

**NG** **REPLACE FUSE**

**OK**

**2 CHECK HARNESS AND CONNECTOR (WOOFER SPEAKER - BATTERY AND BODY GROUND)**



(a) Disconnect the K4 woofer speaker connector.

(b) Measure the voltage.

**Standard voltage**

Tester Connection	Condition	Specified Condition
K4-4 (+B) - Body ground	Always	11 to 14 V
K4-3 (ACC) - Body ground	Ignition switch ACC	11 to 14 V

(c) Measure the resistance.

**Standard resistance**

Tester Connection	Specified Condition
K4-7 (GND) - Body ground	Below 1 Ω

(d) Reconnect the woofer speaker connector.


**NG** **REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**


**AV**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

# RADIO RECEIVER COMPONENTS



AV





AV


$\boxed{\text{N}^*\text{m (kgf}^*\text{cm, ft}^*\text{lbf)}}$  : Specified torque

## REMOVAL

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
2. REMOVE INSTRUMENT PANEL GARNISH RH (See page [IP-10](#))
3. REMOVE INSTRUMENT PANEL GARNISH LH (See page [IR-18](#))
4. REMOVE INTEGRATION CONTROL PANEL ASSEMBLY (See page [SB-2](#))
5. REMOVE RADIO RECEIVER ASSEMBLY
  - (a) Remove the 4 bolts and the radio receiver.



- (b) Disconnect the plug, the head unit connector and the 2 radio connectors.



## DISASSEMBLY

1. REMOVE RADIO BRACKET RH
  - (a) Remove the 4 screws and the radio bracket.
2. REMOVE RADIO BRACKET LH
 

HINT:  
Use the same procedure as for the RH side.

## REASSEMBLY

### 1. INSTALL RADIO BRACKET RH


- (a) Align the 4 bosses of the radio bracket with the hole in the radio receiver and install the radio bracket with the 4 screws.

**Torque: 2.5 N\*m (25 kgf\*cm, 22 in.\*lbf)**

### 2. INSTALL RADIO BRACKET LH

HINT:


Use the same procedure as for the RH side.



## INSTALLATION

### 1. INSTALL RADIO RECEIVER ASSEMBLY

- (a) Connect the plug, the head unit connector and the 2 radio connectors.



- (b) Align the 2 bosses of the radio bracket with the hole in the instrument panel and install the radio receiver with the 4 bolts.

**Torque: 2.5 N\*m (25 kgf\*cm, 22 in.\*lbf)**


### 2. INSTALL INTEGRATION CONTROL PANEL ASSEMBLY (See page [SB-3](#))

### 3. INSTALL INSTRUMENT PANEL GARNISH RH (See page [IP-33](#))

### 4. INSTALL INSTRUMENT PANEL GARNISH LH (See page [IP-33](#))


### 5. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**




# FRONT NO. 1 SPEAKER

## COMPONENTS



AV

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque



## ON-VEHICLE INSPECTION

### 1. INSPECT FRONT NO. 1 SPEAKER ASSEMBLY

#### HINT:

Remove interior parts so that the front No. 1 speaker can be seen.

- (a) Check the speaker installation.

#### OK:

**The speaker is securely installed.**

If the result is not as specified, reinstall the front No. 1 speaker.

- (b) Visually check the speaker.

#### OK:

**The cone paper of the speaker is not torn.**

If the result is not as specified, replace the front No. 1 speaker.

- (c) Check the resistance.

- (1) Disconnect the speaker connector.

- (2) Using an ohmmeter, measure the resistance between the terminals.

#### Standard resistance

Tester Connection	Specified Condition
1 - 2	Approximately 4 $\Omega$



If the result is not as specified, replace the front No. 1 speaker.

## REMOVAL

### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE FRONT DOOR ARMREST BASE UPPER PANEL (See page ED-9)**
3. **REMOVE FRONT DOOR TRIM BOARD SUB-ASSEMBLY (See page ED-9)**
4. **REMOVE FRONT NO. 1 SPEAKER ASSEMBLY**
  - (a) Disconnect the speaker connector.



- (b) Remove the 4 screws and the front No. 1 speaker.


## INSTALLATION

### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

#### 1. INSTALL FRONT NO. 1 SPEAKER ASSEMBLY

- (a) Install the front No. 1 speaker with the 4 screws.  
**Torque: 2.5 N\*m (25 kgf\*cm, 22 in.\*lbf)**




- (b) Connect the speaker connector.

#### 2. INSTALL FRONT DOOR TRIM BOARD SUB-ASSEMBLY (See page [ED-24](#))

#### 3. INSTALL FRONT DOOR ARMREST BASE UPPER PANEL (See page [ED-25](#))

#### 4. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL


**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**



# FRONT NO. 2 SPEAKER


## COMPONENTS

INSTRUMENT PANEL SPEAKER  
PANEL SUB-ASSEMBLY





x2 **8.1 (85, 72 in.\*lbf)**

FRONT NO. 2 SPEAKER  
ASSEMBLY



**2.5 (25, 22 in.\*lbf)**  
x2


FRONT SPEAKER BRACKET



SPEAKER  
CONNECTOR

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

AV



## ON-VEHICLE INSPECTION

### 1. INSPECT FRONT NO. 2 SPEAKER ASSEMBLY

#### HINT:

Remove interior parts so that the front No. 2 speaker can be seen.

- (a) Check the speaker installation.

#### OK:

**The speaker is securely installed.**

If the result is not as specified, reinstall the front No. 2 speaker.

- (b) Visually check the speaker.

#### OK:

**The cone paper of the speaker is not torn.**

If the result is not as specified, replace the front No. 2 speaker.

- (c) Check the resistance.

- (1) Disconnect the speaker connector.

- (2) Using an ohmmeter, measure the resistance between the terminals.

#### Standard resistance

Tester Connection	Specified Condition
3 - 4	Approximately 8 Ω


If the result is not as specified, replace the front No. 2 speaker.

## REMOVAL


### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY (See page [IP-16](#))**
3. **REMOVE FRONT SPEAKER BRACKET**
  - (a) Remove the 2 bolts and the front speaker bracket.
  - (b) Disconnect the speaker connector.




4. **REMOVE FRONT NO. 2 SPEAKER ASSEMBLY**
  - (a) Remove the clamp.
  - (b) Remove the 2 bolts and the front No. 2 speaker.



## INSTALLATION

### HINT:


The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.



### 1. INSTALL FRONT NO. 2 SPEAKER ASSEMBLY

- (a) Install the clamp.
- (b) Insert the 2 hooks into the 2 cutout of the front speaker bracket and install the front No. 2 speaker with the 2 bolts.

**Torque: 8.1 N\*m (85 kgf\*cm, 72 in.\*lbf)**



### 2. INSTALL FRONT SPEAKER BRACKET

- (a) Connect the speaker connector.
- (b) Insert the 2 hooks into the 2 instrument panel holes and install the front speaker bracket with the 2 bolts.

**Torque: 2.5 N\*m (25 kgf\*cm, 22 in.\*lbf)**


### 3. INSTALL INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY (See page [IP-27](#))

### 4. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL


**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**

# REAR SPEAKER COMPONENTS


for RH Side:




for LH Side:



N\*m (kgf\*cm, ft\*lbf) : Specified torque




AV




AV


for RH Side:



AV




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque




AV

$N \cdot m$  (kgf\*cm, ft.\*lbf) : Specified torque

AV



**N\*m (kgf\*cm, ft.\*lbf)** : Specified torque



## ON-VEHICLE INSPECTION

### 1. INSPECT REAR SPEAKER ASSEMBLY

#### HINT:

Remove interior parts so that the rear speaker can be seen.

- (a) Check the speaker installation.

#### OK:

**The speaker is securely installed.**

If the result is not as specified, reinstall the rear speaker.

- (b) Visually check the speaker.

#### OK:

**The cone paper of the speaker is not torn.**

If the result is not as specified, replace the rear speaker.

- (c) Check the resistance.

- (1) Disconnect the speaker connector.

- (2) Using an ohmmeter, measure the resistance between the terminals.

#### Standard resistance

Tester Connection	Specified Condition
1 - 2	Approximately 8 $\Omega$

If the result is not as specified, replace the rear speaker.


## REMOVAL

### HINT:


The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE REAR SEATBACK BOARD CARPET ASSEMBLY**
  - (a) for RH Side:
    - (1) Remove the rear seatback board carpet assembly (See page [SE-43](#)).
  - (b) for LH Side:
    - (1) Remove the rear seatback board carpet assembly (See page [SE-29](#)).
3. **REMOVE REAR SEATBACK ASSEMBLY**
  - (a) for RH Side:
    - (1) Remove the rear seatback assembly (See page [SE-43](#)).
  - (b) for LH Side:
    - (1) Remove the rear seatback assembly (See page [SE-29](#)).
4. **REMOVE REAR FLOOR BOARD (See page [IR-13](#))**
5. **REMOVE REAR FLOOR MAT SUPPORT PLATE (See page [IR-14](#))**
6. **REMOVE LUGGAGE HOLD BELT STRIKER ASSEMBLY (See page [IR-14](#))**
7. **REMOVE REAR FLOOR MAT ASSEMBLY (See page [IR-15](#))**
8. **REMOVE FRONT DOOR SCUFF PLATE (See page [IR-15](#))**
9. **REMOVE ACCESS DOOR SCUFF PLATE (See page [IR-15](#))**
10. **REMOVE FRONT DOOR OPENING TRIM WEATHERSTRIP (See page [SB-56](#))**
11. **REMOVE DECK SIDE GARNISH (w/ Woofer) (See page [IR-18](#))**
12. **REMOVE SPEAKER MOUNTING COVER (w/ Woofer) (See page [AV-90](#))**
13. **REMOVE AMPLIFIER BOX SPEAKER ASSEMBLY (w/ Woofer) (See page [AV-90](#))**
14. **REMOVE PACKAGE HOLDER NET HOOK (w/o Woofer) (See page [SB-57](#))**
15. **REMOVE QUARTER TRIM POCKET TRAY (w/o Woofer) (See page [IR-19](#))**

16. REMOVE SIDE TRIM COVER (w/o Woofer) (See page [IR-19](#))
17. REMOVE QUARTER TRIM POCKET (w/o Woofer) (See page [IR-19](#))
18. REMOVE LAP BELT OUTER ANCHOR COVER (See page [SB-57](#))
19. REMOVE REAR SEAT OUTER BELT ASSEMBLY (See page [IR-20](#))
20. REMOVE REAR DECK TRIM COVER (w/ Power Outlet Socket) (See page [IR-20](#))
21. REMOVE DECK TRIM SIDE PANEL ASSEMBLY
  - (a) for RH Side:
    - (1) Remove the deck trim side panel assembly (See page [IR-21](#)).
  - (b) for LH Side:
    - (1) Remove the deck trim side panel assembly (See page [IR-21](#)).
22. REMOVE ROOF SIDE INNER GARNISH (See page [IR-22](#))



23. REMOVE SPEAKER MOUNTING BRACKET
  - (a) Disconnect the speaker connector.
  - (b) Remove the 2 bolts and the speaker mounting bracket.





24. REMOVE REAR SPEAKER ASSEMBLY
  - (a) Remove the clamp, the 2 bolts and the rear speaker.

## INSTALLATION

### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.



### 1. INSTALL REAR SPEAKER ASSEMBLY

- (a) Inert the 2 hooks into the 2 cutouts of the speaker mounting bracket and install the rear speaker with the 2 bolts.

**Torque: 8.1 N\*m (85 kgf\*cm, 72 in.\*lbf)**

- (b) Install the clamp.

### 2. INSTALL SPEAKER MOUNTING BRACKET

- (a) Install the speaker mounting bracket with the 2 bolts.

**Torque: 8.1 N\*m (85 kgf\*cm, 72 in.\*lbf)**

- (b) Connect the speaker connector.

### 3. INSTALL ROOF SIDE INNER GARNISH (See page [IR-38](#))

### 4. INSTALL DECK TRIM SIDE PANEL ASSEMBLY

- (a) for RH Side:

- (1) Install the deck trim side panel assembly (See page [IR-39](#)).

- (b) for LH Side:

- (1) Install the deck trim side panel assembly (See page [IR-39](#)).

### 5. INSTALL REAR DECK TRIM COVER (w/ Power Outlet Socket) (See page [IR-40](#))

### 6. INSTALL REAR SEAT OUTER BELT ASSEMBLY (See page [IR-40](#))

### 7. INSTALL LAP BELT OUTER ANCHOR COVER (See page [SB-61](#))

### 8. INSTALL AMPLIFIER BOX SPEAKER ASSEMBLY (w/ Woofer) (See page [AV-90](#))

### 9. INSTALL SPEAKER MOUNTING COVER (w/ Woofer) (See page [AV-91](#))

### 10. INSTALL DECK SIDE GARNISH (w/ Woofer) (See page [IR-41](#))

### 11. INSTALL QUARTER TRIM POCKET (w/o Woofer) (See page [IR-41](#))


### 12. INSTALL SIDE TRIM COVER (w/o Woofer) (See page [IR-42](#))

### 13. INSTALL QUARTER TRIM POCKET TRAY (w/o Woofer) (See page [IR-41](#))

14. **INSTALL PACKAGE HOLDER NET HOOK (w/o Woofer) (See page [SB-62](#))**
15. **INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP (See page [SB-62](#))**
16. **INSTALL ACCESS DOOR SCUFF PLATE (See page [IR-45](#))**
17. **INSTALL FRONT DOOR SCUFF PLATE (See page [IR-45](#))**
18. **INSTALL REAR FLOOR MAT ASSEMBLY (See page [IR-46](#))**
19. **INSTALL LUGGAGE HOLD BELT STRIKER ASSEMBLY (See page [IR-46](#))**
20. **INSTALL REAR FLOOR MAT SUPPORT PLATE (See page [IR-46](#))**
21. **INSTALL REAR FLOOR BOARD (See page [IR-47](#))**
22. **INSTALL REAR SEATBACK ASSEMBLY**
  - (a) for RH Side:
    - (1) Install the rear seatback assembly (See page [SE-54](#)).
  - (b) for LH Side:
    - (1) Install the rear seatback assembly (See page [SE-38](#)).
23. **INSTALL REAR SEATBACK BOARD CARPET ASSEMBLY**
  - (a) for RH Side:
    - (1) Install the rear seatback board carpet assembly (See page [SE-54](#)).
  - (b) for LH Side:
    - (1) Install the rear seatback board carpet assembly (See page [SE-38](#)).
24. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**

**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**


# ROOF SPEAKER COMPONENTS




AV

Y

B130654E01






AV



AV


AV






**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

AV




AV

$N \cdot m$  (kgf $\cdot$ cm, ft $\cdot$ lbf) : Specified torque



AV

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque



COAT HOOK

COAT HOOK

ASSIST GRIP ASSEMBLY

ASSIST GRIP PLUG

ASSIST GRIP PLUG

ASSIST GRIP ASSEMBLY


**w/ Curtain Shield Airbag:**

ROOF HEADLINING HOLE PLUG

ROOF HEADLINING HOLE PLUG

AV





## ON-VEHICLE INSPECTION

### 1. INSPECT ROOF SPEAKER ASSEMBLY

#### HINT:

Remove interior parts so that the roof speaker can be seen.

- (a) Check the speaker installation.

#### OK:

**The speaker is securely installed.**

If the result is not as specified, reinstall the roof speaker.

- (b) Visually check the speaker.

#### OK:

**The metal arm of speaker is not bended.**

**The screw of speaker is not loosened.**

If the result is not as specified, replace the roof speaker.

- (c) Check the resistance.

(1) Disconnect the speaker connector.

(2) Using an ohmmeter, measure the resistance between the terminals.

#### Standard resistance

Tester connection	Specified Condition
1 - 2	Approximately 4 Ω

If the result is not as specified, replace the roof speaker.

## REMOVAL




### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE REAR SEATBACK BOARD CARPET ASSEMBLY RH (See page [SE-43](#))**
3. **REMOVE REAR SEATBACK ASSEMBLY RH (See page [SE-43](#))**
4. **REMOVE REAR SEATBACK BOARD CARPET ASSEMBLY LH (See page [SE-29](#))**
5. **REMOVE REAR SEATBACK ASSEMBLY LH (See page [SE-29](#))**
6. **REMOVE REAR FLOOR BOARD (See page [IR-13](#))**
7. **REMOVE REAR FLOOR MAT SUPPORT PLATE (See page [IR-14](#))**
8. **REMOVE LUGGAGE HOLD BELT STRIKER ASSEMBLY (See page [IR-14](#))**
9. **REMOVE REAR FLOOR MAT ASSEMBLY (See page [IR-15](#))**
10. **REMOVE FRONT DOOR SCUFF PLATE RH (See page [IR-15](#))**
11. **REMOVE FRONT DOOR SCUFF PLATE LH (See page [IR-15](#))**
12. **REMOVE ACCESS DOOR SCUFF PLATE RH (See page [IR-15](#))**
13. **REMOVE ACCESS DOOR SCUFF PLATE LH (See page [IR-15](#))**
14. **REMOVE FRONT FLOOR FOOTREST (See page [IR-2](#))**
15. **REMOVE FOOTREST CLIP (See page [IR-2](#))**
16. **REMOVE COWL SIDE TRIM BOARD RH (See page [IR-15](#))**
17. **REMOVE COWL SIDE TRIM BOARD LH (See page [IR-15](#))**
18. **REMOVE ROOF SIDE INNER GARNISH COVER RH (See page [IR-16](#))**
19. **REMOVE ROOF SIDE INNER GARNISH COVER LH (See page [IR-16](#))**
20. **REMOVE ROOF SIDE RAIL GARNISH RH (See page [IR-16](#))**
21. **REMOVE ROOF SIDE RAIL GARNISH LH (See page [IR-16](#))**


22. REMOVE FRONT DOOR OPENING TRIM WEATHERSTRIP RH (See page [IR-16](#))
23. REMOVE FRONT DOOR OPENING TRIM WEATHERSTRIP LH (See page [IR-16](#))
24. REMOVE ASSIST GRIP PLUG (See page [IR-17](#))
25. REMOVE ASSIST GRIP ASSEMBLY (See page [IR-17](#))
26. REMOVE FRONT PILLAR GARNISH RH (See page [IR-18](#))
27. REMOVE FRONT PILLAR GARNISH LH (See page [IR-18](#))
28. REMOVE DECK SIDE GARNISH (w/ Woofer) (See page [IR-18](#))
29. REMOVE SPEAKER MOUNTING COVER (w/ Woofer) (See page [AV-90](#))
30. REMOVE AMPLIFIER BOX SPEAKER ASSEMBLY (w/ Woofer) (See page [AV-90](#))
31. REMOVE PACKAGE HOLDER NET HOOK (See page [IR-18](#))
32. REMOVE QUARTER TRIM POCKET TRAY (w/o Woofer) (See page [IR-19](#))
33. REMOVE SIDE TRIM COVER (w/o Woofer) (See page [IR-19](#))
34. REMOVE QUARTER TRIM POCKET (w/o Woofer) (See page [IR-19](#))
35. REMOVE LAP BELT OUTER ANCHOR COVER (See page [IR-20](#))
36. REMOVE REAR SEAT OUTER BELT ASSEMBLY RH (See page [IR-20](#))
37. REMOVE REAR SEAT OUTER BELT ASSEMBLY LH (See page [IR-20](#))
38. REMOVE REAR DECK TRIM COVER (w/ Power Outlet Socket) (See page [IR-20](#))
39. REMOVE DECK TRIM SIDE PANEL ASSEMBLY RH (See page [IR-21](#))
40. REMOVE DECK TRIM SIDE PANEL ASSEMBLY LH (See page [IR-21](#))
41. REMOVE ROOF SIDE INNER GARNISH RH (See page [IR-22](#))
42. REMOVE ROOF SIDE INNER GARNISH LH (See page [IR-22](#))
43. REMOVE ROOF HEADLINING HOLE PLUG (w/ Curtain Shield Airbag) (See page [IR-23](#))
44. REMOVE COAT HOOK (See page [IR-24](#))
45. REMOVE VISOR ASSEMBLY RH (See page [IR-24](#))

46. REMOVE VISOR ASSEMBLY LH (See page [IR-24](#))
47. REMOVE VISOR HOLDER (See page [IR-25](#))
48. REMOVE INNER REAR VIEW MIRROR STAY HOLDER COVER (See page [MI-6](#))
49. REMOVE INNER REAR VIEW MIRROR ASSEMBLY (See page [MI-6](#))
50. REMOVE ROOM LIGHT ASSEMBLY (See page [IR-25](#))
51. REMOVE ROOF HEADLINING
  - (a) Using a clip remover, remove the 3 clamps and the connector.
  - (b) Using a clip remover, remove the 4 clips.



**52. REMOVE ROOF SPEAKER ASSEMBLY**

- (a) Disconnect the speaker connector.
- (b) Loosen the screw.



- (c) Remove the roof speaker by turning it in the direction of the arrow shown in the illustration.


## INSTALLATION

### HINT:

The procedure described below is for the RH side. Use the same procedure for both the RH and LH sides, unless otherwise specified.

#### 1. INSTALL ROOF SPEAKER ASSEMBLY




- (a) Install the roof speaker by turning it in the direction of the arrow shown in the illustration.



- (b) Tighten the screw.
- (c) Connect the speaker connector.

#### 2. INSTALL ROOF HEADLINING

- (a) Install the roof headlining with the 4 clips.



- (b) Install the 3 clamps and the connector.


3. **INSTALL ROOM LIGHT ASSEMBLY** (See page [IR-34](#))
4. **INSTALL INNER REAR VIEW MIRROR ASSEMBLY** (See page [MI-6](#))
5. **INSTALL INNER REAR VIEW MIRROR STAY HOLDER COVER** (See page [MI-6](#))
6. **INSTALL VISOR HOLDER** (See page [IR-36](#))
7. **INSTALL VISOR ASSEMBLY RH** (See page [IR-36](#))

8. INSTALL VISOR ASSEMBLY LH (See page [IR-36](#))
9. INSTALL COAT HOOK (See page [IR-36](#))
10. INSTALL ROOF HEADLINING HOLE PLUG (w/ Curtain Shield Airbag) (See page [IR-37](#))
11. INSTALL ROOF SIDE INNER GARNISH RH (See page [IR-38](#))
12. INSTALL ROOF SIDE INNER GARNISH LH (See page [IR-38](#))
13. INSTALL DECK TRIM SIDE PANEL ASSEMBLY RH (See page [IR-39](#))
14. INSTALL DECK TRIM SIDE PANEL ASSEMBLY LH (See page [IR-39](#))
15. INSTALL REAR DECK TRIM COVER (w/ Power Outlet Socket) (See page [IR-40](#))
16. INSTALL REAR SEAT OUTER BELT ASSEMBLY RH (See page [IR-40](#))
17. INSTALL REAR SEAT OUTER BELT ASSEMBLY LH (See page [IR-40](#))
18. INSTALL LAP BELT OUTER ANCHOR COVER (See page [IR-41](#))
19. INSTALL AMPLIFIER BOX SPEAKER ASSEMBLY (w/ Woofer) (See page [AV-90](#))
20. INSTALL SPEAKER MOUNTING COVER (w/ Woofer) (See page [AV-91](#))
21. INSTALL DECK SIDE GARNISH (w/ Woofer) (See page [IR-41](#))
22. INSTALL QUARTER TRIM POCKET (w/o Woofer) (See page [IR-41](#))
23. INSTALL SIDE TRIM COVER (w/o Woofer) (See page [IR-42](#))
24. INSTALL QUARTER TRIM POCKET TRAY (w/o Woofer) (See page [IR-42](#))
25. INSTALL PACKAGE HOLDER NET HOOK (See page [IR-42](#))
26. INSTALL FRONT PILLAR GARNISH RH (See page [IR-43](#))
27. INSTALL FRONT PILLAR GARNISH LH (See page [IR-43](#))
28. INSTALL ASSIST GRIP ASSEMBLY (See page [IR-43](#))
29. INSTALL ASSIST GRIP PLUG (See page [IR-44](#))
30. INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP RH (See page [IR-44](#))
31. INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP LH (See page [IR-44](#))

32. INSTALL ROOF SIDE RAIL GARNISH RH (See page [IR-44](#))
33. INSTALL ROOF SIDE RAIL GARNISH LH (See page [IR-44](#))
34. INSTALL ROOF SIDE INNER GARNISH COVER RH (See page [IR-45](#))
35. REMOVE ROOF SIDE INNER GARNISH COVER LH (See page [IR-45](#))
36. INSTALL COWL SIDE TRIM BOARD RH (See page [IR-45](#))
37. INSTALL COWL SIDE TRIM BOARD LH (See page [IR-45](#))
38. INSTALL FOOTREST CLIP (See page [IR-2](#))
39. INSTALL FRONT FLOOR FOOTREST (See page [IR-2](#))
40. INSTALL ACCESS DOOR SCUFF PLATE RH (See page [IR-45](#))
41. INSTALL ACCESS DOOR SCUFF PLATE LH (See page [IR-45](#))
42. INSTALL FRONT DOOR SCUFF PLATE RH (See page [IR-45](#))
43. INSTALL FRONT DOOR SCUFF PLATE LH (See page [IR-45](#))
44. INSTALL REAR FLOOR MAT ASSEMBLY (See page [IR-46](#))
45. INSTALL LUGGAGE HOLD BELT STRIKER ASSEMBLY (See page [IR-46](#))
46. INSTALL REAR FLOOR MAT SUPPORT PLATE (See page [IR-46](#))
47. INSTALL REAR FLOOR BOARD (See page [IR-47](#))
48. INSTALL REAR SEATBACK ASSEMBLY RH (See page [SE-54](#))
49. INSTALL REAR SEATBACK BOARD CARPET ASSEMBLY RH (See page [SE-54](#))
50. INSTALL REAR SEATBACK ASSEMBLY LH (See page [SE-38](#))
51. INSTALL REAR SEATBACK BOARD CARPET ASSEMBLY LH (See page [SE-38](#))
52. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL  
Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)

# AMPLIFIER BOX SPEAKER ASSEMBLY

## COMPONENTS




AV


**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

## REMOVAL

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE DECK SIDE GARNISH** (See page [IR-18](#))
3. **REMOVE SPEAKER MOUNTING COVER**
  - (a) Disengage the 8 clips and remove the speaker mounting cover.





4. **REMOVE AMPLIFIER BOX SPEAKER ASSEMBLY**
  - (a) Disconnect the speaker connector.
  - (b) Remove the 4 screws and the amplifier box speaker.



## INSTALLATION

1. **INSTALL AMPLIFIER BOX SPEAKER ASSEMBLY**
  - (a) Install the amplifier box speaker with the 4 screws.  
**Torque: 8.1 N\*m (85 kgf\*cm, 72 in.\*lbf)**
  - (b) Connect the speaker connector.






2. **INSTALL SPEAKER MOUNTING COVER**
  - (a) Engage the 8 clips and install the speaker mounting cover.
3. **INSTALL DECK SIDE GARNISH (See page [IR-41](#))**
4. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**  
**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**


# RADIO ANTENNA CORD

## COMPONENTS



for Automatic Transmission 4WD:


SHIFT LEVER KNOB  
SUB-ASSEMBLY




for Manual Transmission:

SHIFT LEVER KNOB  
SUB-ASSEMBLY

SHIFT LEVER KNOB  
SUB-ASSEMBLY




PARKING BRAKE HOLE  
COVER SUB-ASSEMBLY




FRONT CONSOLE BOX UPPER  
PANEL SUB-ASSEMBLY

x4




FRONT CONSOLE BOX  
BOTTOM MAT




FRONT CONSOLE BOX

AV



AV

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque



AV

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

INSTRUMENT PANEL SPEAKER  
PANEL SUB-ASSEMBLY RH



INSTRUMENT PANEL SPEAKER  
PANEL SUB-ASSEMBLY LH

2.5 (25, 22 in.\*lbf)

x2



FRONT NO. 2 SPEAKER  
ASSEMBLY

x2


2.5 (25, 22 in.\*lbf)



FRONT NO. 2 SPEAKER  
ASSEMBLY



INSTRUMENT PANEL  
FINISH PANEL END



INSTRUMENT PANEL  
SUB-ASSEMBLY

x2


x2

20 (204, 15)

x7

N\*m (kgf\*cm, ft\*lbf) : Specified torque

AV



AV

## REMOVAL

### CAUTION:

Some of these service operations affect the SRS airbag system. Read the precautionary notices concerning the SRS airbag system before servicing (See page [RS-1](#)).


1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL


### CAUTION:

Wait for at least 90 seconds after disconnecting the cable to prevent the airbag from working.

2. REMOVE FRONT DOOR SCUFF PLATE RH (See page [IR-15](#))
3. REMOVE FRONT DOOR SCUFF PLATE LH (See page [IR-15](#))
4. REMOVE FRONT FLOOR FOOTREST (See page [IR-2](#))
5. REMOVE FOOTREST CLIP (See page [IR-2](#))
6. REMOVE COWL SIDE TRIM BOARD RH (See page [IR-15](#))
7. REMOVE COWL SIDE TRIM BOARD LH (See page [IR-15](#))
8. SEPARATE FRONT DOOR OPENING TRIM WEATHERSTRIP RH
  - (a) Remove the front door opening trim weatherstrip to the extent that the front pillar garnish and the instrument panel lower finish panel can be removed.
9. SEPARATE FRONT DOOR OPENING TRIM WEATHERSTRIP LH
 


HINT:  
Use the same procedure as for the RH side.



**10. REMOVE ASSIST GRIP PLUG****HINT:**

Use the same procedure to remove all the assist grip plugs.

- (a) Using a screwdriver with its tip wrapped in protective tape, disengage the 2 claws and remove the assist grip plug.


**11. REMOVE ASSIST GRIP ASSEMBLY****HINT:**

Use the same procedure to remove all the assist grips.

- (a) Remove the 2 screws and the assist grip.


**12. REMOVE FRONT PILLAR GARNISH RH (See page [IR-18](#))****13. REMOVE FRONT PILLAR GARNISH LH (See page [IR-18](#))****14. REMOVE ASSIST GRIP RETAINER RH (See page [IP-16](#))****15. REMOVE ASSIST GRIP RETAINER LH (See page [IP-16](#))****16. REMOVE INSTRUMENT PANEL GARNISH LH (See page [IP-10](#))****17. REMOVE INSTRUMENT PANEL GARNISH RH (See page [IP-10](#))****18. REMOVE INTEGRATION CONTROL PANEL ASSEMBLY (See page [IP-11](#))****19. REMOVE RADIO RECEIVER ASSEMBLY (See page [AV-55](#))****20. REMOVE PARKING BRAKE HOLE COVER SUB-ASSEMBLY (See page [IP-11](#))****21. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transmission) (See page [IP-11](#))****22. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for 4WD) (See page [IP-11](#))**

23. REMOVE FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY (See page [IP-12](#))
24. REMOVE FRONT CONSOLE BOX BOTTOM MAT (See page [IP-12](#))
25. REMOVE FRONT CONSOLE BOX (See page [IP-12](#))
26. REMOVE FRONT CONSOLE BOX UPPER PANEL GARNISH (See page [IP-12](#))
27. REMOVE INSTRUMENT LOWER COVER SUB-ASSEMBLY (See page [IP-13](#))
28. REMOVE INSTRUMENT PANEL REGISTER ASSEMBLY LH (See page [IP-13](#))
29. REMOVE HOOD LOCK CONTROL LEVER SUB-ASSEMBLY (See page [IP-13](#))
30. REMOVE INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY LH (See page [IP-14](#))
31. REMOVE INSTRUMENT LOWER PANEL (See page [IP-14](#))
32. REMOVE INSTRUMENT CLUSTER LOWER FINISH PANEL (See page [IP-14](#))
33. REMOVE COMBINATION METER ASSEMBLY (See page [IP-14](#))
34. REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-15](#))
35. REMOVE INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY RH (See page [IP-15](#))
36. REMOVE INSTRUMENT PANEL REGISTER ASSEMBLY RH (See page [IP-16](#))
37. REMOVE INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY RH (See page [IP-16](#))
38. REMOVE INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY LH (See page [IP-16](#))

**39. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY****HINT:**

Use the same procedure for both sides.

- (a) Remove the 2 bolts and the front No. 2 speaker.
- (b) Disconnect the speaker connector.

**40. DISCONNECT PASSENGER AIRBAG CONNECTOR  
(See page IP-16)****41. REMOVE INSTRUMENT PANEL SUB-ASSEMBLY  
(See page IP-16)****42. REMOVE INSTRUMENT PANEL FINISH PANEL END  
(See page IP-21)****43. REMOVE ANTENNA CORD SUB-ASSEMBLY**


- (a) Disengage the 4 clamps.

- (b) Remove the 3 pieces of tape and the antenna cord.


## INSTALLATION

### CAUTION:

Some of these service operations affect the SRS airbag system. Read the precautionary notices concerning the SRS airbag system before servicing (See page [RS-1](#)).




1. **INSTALL ANTENNA CORD SUB-ASSEMBLY**
  - (a) Install the antenna cord with 3 new pieces of tape.
  - (b) Engage the 4 clamps.
2. **INSTALL INSTRUMENT PANEL SUB-ASSEMBLY** (See page [IP-26](#))
3. **CONNECT PASSENGER AIRBAG CONNECTOR** (See page [IP-26](#))
4. **INSTALL INSTRUMENT PANEL FINISH PANEL END** (See page [IP-27](#))



5. **INSTALL FRONT NO. 2 SPEAKER ASSEMBLY**  
**HINT:**  
 Use the same procedure for both sides.
  - (a) Connect the speaker connector.
  - (b) Insert the 2 hooks into the instrument panel and install the front No. 2 speaker with the 2 bolts.  
**Torque: 2.5 N\*m (25 kgf\*cm, 22 in.\*lbf)**
6. **INSTALL INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY RH** (See page [IP-27](#))
7. **INSTALL INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY LH** (See page [IP-27](#))
8. **INSTALL INSTRUMENT PANEL REGISTER ASSEMBLY RH** (See page [IP-27](#))
9. **INSTALL INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY RH** (See page [IP-28](#))
10. **INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY** (See page [IP-28](#))
11. **INSTALL COMBINATION METER ASSEMBLY** (See page [IP-28](#))
12. **INSTALL INSTRUMENT CLUSTER LOWER FINISH PANEL** (See page [IP-29](#))
13. **INSTALL INSTRUMENT LOWER PANEL** (See page [IP-29](#))
14. **INSTALL INSTRUMENT PANEL LOWER FINISH PANEL SUB-ASSEMBLY LH** (See page [IP-29](#))
15. **INSTALL HOOD LOCK CONTROL LEVER SUB-ASSEMBLY** (See page [IP-30](#))

16. INSTALL INSTRUMENT PANEL REGISTER ASSEMBLY LH (See page [IP-30](#))
17. INSTALL INSTRUMENT LOWER COVER SUB-ASSEMBLY (See page [IP-30](#))
18. INSTALL FRONT CONSOLE BOX UPPER PANEL GARNISH (See page [IP-31](#))
19. INSTALL FRONT CONSOLE BOX (See page [IP-31](#))
20. INSTALL FRONT CONSOLE BOX BOTTOM MAT (See page [IP-31](#))
21. INSTALL FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY (See page [IP-31](#))
22. INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for 4WD) (See page [IP-32](#))
23. INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transmission) (See page [IP-32](#))
24. INSTALL PARKING BRAKE HOLE COVER SUB-ASSEMBLY (See page [IP-32](#))
25. INSTALL RADIO RECEIVER ASSEMBLY (See page [AV-56](#))
26. INSTALL INTEGRATION CONTROL PANEL ASSEMBLY (See page [IP-32](#))
27. INSTALL INSTRUMENT PANEL GARNISH LH (See page [IP-33](#))
28. INSTALL INSTRUMENT PANEL GARNISH RH (See page [IR-43](#))
29. INSTALL ASSIST GRIP RETAINER RH (See page [IP-27](#))
30. INSTALL ASSIST GRIP RETAINER LH (See page [IP-27](#))
31. INSTALL FRONT PILLAR GARNISH RH (See page [IR-43](#))
32. INSTALL FRONT PILLAR GARNISH LH (See page [IR-43](#))




**33. INSTALL ASSIST GRIP ASSEMBLY**

HINT:

Use the same procedure to install all the assist grips.

- (a) Install the assist grip with the 2 screws.




**34. INSTALL ASSIST GRIP PLUG**

HINT:

Use the same procedure to install all the assist grip plugs.

- (a) Engage the 2 claws and install the assist grip plug.



**35. INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP RH**

- (a) Install the front door opening trim weatherstrip.

**36. INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP LH**

HINT:

Use the same procedure as for the RH side.


**37. INSTALL COWL SIDE TRIM BOARD RH (See page IR-45)**

AV


38. **INSTALL COWL SIDE TRIM BOARD LH** (See page [IR-45](#))
39. **INSTALL FOOTREST CLIP** (See page [IR-2](#))
40. **INSTALL FRONT FLOOR FOOTREST** (See page [IR-2](#))
41. **INSTALL FRONT DOOR SCUFF PLATE RH** (See page [IR-45](#))
42. **INSTALL FRONT DOOR SCUFF PLATE LH** (See page [IR-45](#))
43. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**  
Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)
44. **INSPECT SRS WARNING LIGHT**  
(See page [RS-29](#))

# RADIO ANTENNA HOLDER



## COMPONENTS



AV




AV




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

w/ Side Step:




AV

$\boxed{\text{N*m (kgf*cm, ft*lbf)}}$  : Specified torque




AV



**N\*m (kgf\*cm, ft\*lbf) : Specified torque**

● Non-reusable part

Y





AV

**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

## REMOVAL


1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE GLOVE COMPARTMENT DOOR ASSEMBLY (See page [IP-15](#))**
3. **REMOVE FRONT DOOR OPENING TRIM WEATHERSTRIP**
  - (a) Remove the front door opening trim weatherstrip to the extent that the front pillar garnish can be removed.



4. **REMOVE ASSIST GRIP PLUG**

HINT:  
Use the same procedure for both sides.

  - (a) Using a screwdriver with its tip wrapped in protective tape, disengage the 2 claws and remove the assist grip plug.



5. **REMOVE ASSIST GRIP ASSEMBLY**
  - (a) Remove the 2 screws and the assist grip.
6. **REMOVE FRONT PILLAR GARNISH (See page [IR-18](#))**
7. **REMOVE RADIATOR GRILLE (See page [ET-4](#))**
8. **REMOVE FRONT BUMPER COVER (See page [ET-65](#))**
9. **REMOVE SIDE STEP SUB-ASSEMBLY (w/ Side Step)**

HINT:  
Use the same procedure as for the LH side (See page [ET-86](#)).
10. **REMOVE ROCKER PANEL MOULDING**

HINT:  
Use the same procedure as for the LH side (See page [ET-66](#)).
11. **REMOVE FRONT FENDER MUDGUARD**

HINT:  
Use the same procedure as for the LH side (See page [ET-83](#)).

**12. REMOVE FRONT BUMPER SIDE SUPPORT**


HINT:

Use the same procedure as for the LH side (See page [ET-5](#)).**13. REMOVE FRONT FENDER MOULDING SUB-ASSEMBLY**


HINT:


Use the same procedure as for the LH side (See page [ET-67](#)).**14. REMOVE RADIO ANTENNA POLE SUB-ASSEMBLY (See page [AV-116](#))****15. REMOVE ANTENNA ORNAMENT (See page [WW-26](#))****16. REMOVE FRONT FENDER SIDE UPPER PANEL (See page [WW-26](#))****17. REMOVE FENDER SPLASH REAR SHIELD SUB-ASSEMBLY**

- (a) Remove the 3 clips and the fender splash rear shield to extent that the radio antenna holder can be removed.


**18. REMOVE RADIO ANTENNA HOLDER ASSEMBLY**

- (a) Disconnect the connector.  
 (b) Using a clip remover, remove the 2 clamps and the connector.  
 (c) Remove the grommet and insert the feeder line through the body hole.






- (d) Remove the 2 bolts, the hook and the radio antenna holder.




## INSTALLATION

1. **INSTALL RADIO ANTENNA HOLDER ASSEMBLY**
  - (a) Hook the body side bracket onto the hook of the radio antenna holder and provisionally install the radio antenna holder.
  - (b) Insert the feeder line through the body hole and install the grommet.
  - (c) Tighten bolt A and then bolt B.  
**Torque: 8.4 N\*m (85 kgf\*cm, 74 in.\*lbf)**


AV




- (d) Install the 2 clamps and the connector.
- (e) Connect the connector.




2. **INSTALL FENDER SPLASH REAR SHIELD SUB-ASSEMBLY**  
(a) Install the fender splash rear shield with the 3 clips.
3. **INSTALL FRONT FENDER SIDE UPPER PANEL** (See page [WW-31](#))
4. **INSTALL ANTENNA ORNAMENT** (See page [WW-31](#))
5. **INSTALL RADIO ANTENNA POLE SUB-ASSEMBLY** (See page [AV-116](#))
6. **INSTALL FRONT FENDER MOULDING SUB-ASSEMBLY**  
HINT:  
Use the same procedure as for the LH side (See page [ET-77](#)).
7. **INSTALL FRONT BUMPER SIDE SUPPORT**  
HINT:  
Use the same procedure as for the LH side (See page [ET-9](#)).
8. **INSTALL FRONT FENDER MUDGUARD**  
HINT:  
Use the same procedure as for the LH side (See page [ET-84](#)).
9. **INSTALL ROCKER PANEL MOULDING**  
HINT:  
Use the same procedure as for the LH side (See page [ET-78](#)).
10. **INSTALL SIDE STEP SUB-ASSEMBLY (w/ Side Step)**  
HINT:  
Use the same procedure as for the LH side (See page [ET-87](#)).
11. **INSTALL FRONT BUMPER COVER** (See page [ET-79](#))
12. **INSTALL RADIATOR GRILLE** (See page [ET-11](#))
13. **INSTALL FRONT PILLAR GARNISH** (See page [IR-43](#))
14. **INSTALL ASSIST GRIP ASSEMBLY**  
(a) Install the assist grip with the 2 screws.



**15. INSTALL ASSIST GRIP PLUG****HINT:**

Use the same procedure for both sides.

- (a) Engage the 2 claws and install the assist grip plug.

**16. INSTALL FRONT DOOR OPENING TRIM WEATHERSTRIP**


- (a) Install the front door opening trim weatherstrip.

**17. INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY**  
(See page [IP-28](#))**18. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**

**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**

# RADIO ANTENNA POLE

## COMPONENTS




AV

## REMOVAL

### 1. REMOVE RADIO ANTENNA POLE SUB-ASSEMBLY

- Remove the radio antenna pole by turning it in the direction of the arrow shown in the illustration.



## INSTALLATION


### 1. INSTALL RADIO ANTENNA POLE SUB-ASSEMBLY

- Install the radio antenna pole by turning it in the direction of the arrow shown in the illustration.

**Torque: 3.3 N\*m (35 kgf\*cm, 29 in.\*lbf)**

**NOTICE:**

**Use a short wrench, tighten with your finger, not your hand.**




# STEREO JACK ADAPTER ASSEMBLY

## COMPONENTS

for Automatic Transmission 4WD:


SHIFT LEVER KNOB  
SUB-ASSEMBLY



for Manual Transmission:

SHIFT LEVER KNOB  
SUB-ASSEMBLY

SHIFT LEVER KNOB  
SUB-ASSEMBLY



PARKING BRAKE HOLE  
COVER SUB-ASSEMBLY


FRONT CONSOLE BOX UPPER  
PANEL SUB-ASSEMBLY

x4

FRONT CONSOLE BOX  
BOTTOM MAT

FRONT CONSOLE BOX



AV



AV

## REMOVAL

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
2. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transmission) (See page [IP-11](#))
3. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for 4WD) (See page [IP-11](#))
4. REMOVE PARKING BRAKE HOLE COVER SUB-ASSEMBLY (See page [IP-11](#))
5. REMOVE FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY (See page [IP-12](#))
6. REMOVE FRONT CONSOLE BOX BOTTOM MAT (See page [IP-12](#))
7. REMOVE FRONT CONSOLE BOX (See page [IP-12](#))
8. REMOVE INSTRUMENT LOWER COVER SUB-ASSEMBLY (See page [IP-13](#))
9. REMOVE STEREO JACK ADAPTER ASSEMBLY
  - (a) Disengage the 2 claws and remove the stereo jack adapter.



## INSTALLATION


1. INSTALL STEREO JACK ADAPTER ASSEMBLY
  - (a) Engage the 2 claws and install the stereo jack adapter.
2. INSTALL INSTRUMENT LOWER COVER SUB-ASSEMBLY (See page [IP-30](#))
3. INSTALL FRONT CONSOLE BOX (See page [IP-31](#))
4. INSTALL FRONT CONSOLE BOX BOTTOM MAT (See page [IP-31](#))
5. INSTALL FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY (See page [IP-31](#))
6. INSTALL PARKING BRAKE HOLE COVER SUB-ASSEMBLY (See page [IP-32](#))
7. INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for 4WD) (See page [IP-32](#))
8. INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transmission) (See page [IP-32](#))

**9. CONNECT CABLE TO NEGATIVE BATTERY  
TERMINAL**

**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**

# STEERING PAD SWITCH

## COMPONENTS



AV

## REMOVAL

### CAUTION:

Some of these service operations affect the SRS airbag system. Read the precautionary notices concerning the SRS airbag system before servicing (See page [RS-1](#)).

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**

### CAUTION:

Wait for at least 90 seconds after disconnecting the cable to prevent the airbag from working.

2. **REMOVE STEERING WHEEL LOWER COVER LH**  
(See page [RS-345](#))


3. **REMOVE STEERING WHEEL LOWER COVER RH**  
(See page [RS-345](#))


4. **REMOVE STEERING PAD** (See page [RS-346](#))

5. **REMOVE STEERING PAD SWITCH**

(a) w/ Cruise Control System:

- (1) Disconnect the cruise control switch connector.
- (b) Disconnect the connector.
- (c) Remove the screw.
- (d) Disengage the 2 claws and the pin and remove the steering pad switch.





## INSPECTION

### 1. INSPECT STEERING PAD SWITCH

(a) Check the resistance.

- (1) Using an ohmmeter, measure the resistance between the terminals.

#### Standard resistance

Tester Connection	Condition	Specified Condition
12 (AU1) - 10 (EAU)	All switches released	Approximately 100 kΩ
	SEEK+ switch: pushed in	2.5 Ω or less
	SEEK- switch: pushed in	Approximately 329 Ω
	VOL+ switch: pushed in	Approximately 1000 Ω
11 (AU2) - 10 (EAU)	All switches released	Approximately 100 kΩ
	MODE switch: push in	2.5 Ω or less

If the result is not as specified, replace the steering pad switch.

(b) Check the operation.

- (1) Apply battery voltage to the terminals and check that the indicator illuminates.

#### Standard


Condition	Standard
Positive battery - Terminal 1 (IL+2) Negative battery - Terminal 10 (EAU)	Illuminates

If the result is not as specified, replace the steering switch.

## INSTALLATION

### CAUTION:

Some of these service operations affect the SRS airbag system. Read the precautionary notices concerning the SRS airbag system before servicing (See page [RS-1](#)).




1. **INSTALL STEERING PAD SWITCH**
  - (a) Engage the 2 claws and the pin and install the steering pad.
  - (b) Tighten the screw.  
**Torque: 2.4 N\*m (24 kgf\*cm, 21 in.\*lbf)**
  - (c) Connect the connector.
  - (d) w/ Cruise Control System:
    - (1) Connect the cruise control switch connector.
2. **INSTALL STEERING PAD (See page [RS-346](#))**
3. **INSTALL STEERING WHEEL LOWER COVER LH (See page [RS-347](#))**
4. **INSTALL STEERING WHEEL LOWER COVER RH (See page [RS-347](#))**
5. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**  
**Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)**
6. **INSPECT SRS WARNING LIGHT (See page [RS-29](#))**

# WOOFER SPEAKER SWITCH

## COMPONENTS

for Automatic Transmission 4WD:



SHIFT LEVER KNOB  
SUB-ASSEMBLY




for Manual Transmission:

SHIFT LEVER KNOB  
SUB-ASSEMBLY

SHIFT LEVER KNOB  
SUB-ASSEMBLY





AV



AV

## REMOVAL

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
2. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transmission) (See page IP-11)
3. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for 4WD) (See page IP-11)
4. REMOVE PARKING BRAKE HOLE COVER SUB-ASSEMBLY (See page IP-11)
5. REMOVE FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY (See page IP-12)
6. REMOVE FRONT CONSOLE BOX BOTTOM MAT (See page IP-12)
7. REMOVE FRONT CONSOLE BOX (See page IP-12)
8. REMOVE INSTRUMENT LOWER COVER SUB-ASSEMBLY (See page IP-13)
9. REMOVE WOOFER SPEAKER SWITCH
  - (a) Disengage the 2 claws and remove the woofer speaker switch.




## INSPECTION

1. INSPECT WOOFER SPEAKER SWITCH
  - (a) Check the resistance.
    - (1) Using an ohmmeter, measure the resistance between the terminals.

### Standard resistance

Tester Connection	Condition	Specified Condition
3 (IN) - 4 (OUT)	OFF	10 kΩ or higher
	ON	Below 1 Ω

If the result is not as specified, replace the woofer speaker switch.



## INSTALLATION

1. **INSTALL WOOFER SPEAKER SWITCH**
  - (a) Engage the 2 claws and install the woofer speaker switch.
2. **INSTALL INSTRUMENT LOWER COVER SUB-ASSEMBLY** (See page [IP-30](#))
3. **INSTALL FRONT CONSOLE BOX** (See page [IP-31](#))
4. **INSTALL FRONT CONSOLE BOX BOTTOM MAT** (See page [IP-31](#))
5. **INSTALL FRONT CONSOLE BOX UPPER PANEL SUB-ASSEMBLY** (See page [IP-31](#))
6. **INSTALL PARKING BRAKE HOLE COVER SUB-ASSEMBLY** (See page [IP-32](#))
7. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY** (for 4WD) (See page [IP-32](#))
8. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY** (for Manual Transmission) (See page [IP-32](#))
9. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**  
Torque: 3.9 N\*m (40 kgf\*cm, 35 in.\*lbf)